


SYMPHONY

6001
INSTRUCTION MANUAL



EN

This instruction guide contains important information on how to install, operate and maintain LED mirrors.
Please read carefully and save for future reference.




Warnings - Notes

DANGER! Risk of personal injury. Avoid possible electrical shock.


- Dissonnect all power sources before starting installation and maintenance
- This fixture is designed for indoor use and surface mount ONLY

DIR


PRODUCT SPECIFICATIONS



Front view



Side view



Back view

DIR

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED FOR ASSEMBLY (Not in the package)



Level

x1



Impact Drill

x1



Electric Drill

x1



Tape Measure


x1



Pencil


x1

PARTS REQUIRED FOR ASSEMBLY (Included in the package)



Wall bracket

x2



Tapping screw

x6




Plastic expansion anchor
(for drywall)

x10



Wire clips

x1



Glass clamp

x1




Tapping screw

x4



Screw




x4



Glass

x1

ASSEMBLY INSTRUCTIONS




STEP 1

Determine installation location.

Set position above ground based on preference.




ASSEMBLY INSTRUCTIONS



STEP 2

Insert the expansion anchors into the drywall at the marked position.


ASSEMBLY INSTRUCTIONS



STEP 3

Install wall brackets




ASSEMBLY INSTRUCTIONS



STEP 4

Locate and confirm power supply location prior to mounting station. Be sure to secure the station onto the installed wall brackets. Adjust Salon Station left to right to verify unit is securely placed onto the brackets.


ASSEMBLY INSTRUCTIONS



DIR

OPERATION INSTRUCTIONS


ON / OFF Operation: Simply tap the On/Off switch with the tip of your finger to operate the LED Lighting System



SPECIFICATIONS

Specifications	Symbol	6001
Width	W	30 1/4" Wide
Height	H	75 1/2" Long
Depth	D	1 3/4"
Electrical (USA)		110-120V,60W
Electrical (Britain)		220-240V,60W

Product care



Do not use abrasive cleaners that could scratch the mirror. Acidic, alkali or extra strength ammonia cleaners should be avoided as these can damage the copper coating and harm the mirror surface.

Warranty

The warranty period is one year. DIR warrants to you, the original buyer, that goods shall be free of defects in material and/or workmanship attributable to manufacture for one year from date of receipt of product. Damage resulting from improper handling after merchandise is received, or from exposure to weather or extreme atmospheric conditions is not covered by the warranty. For any other information please contact our support team:

DIR Birmingham

66 Rea Street South
Birmingham
B5 6LB

Email: dirsalon@gmail.com
Phone: +44 (0) 121 6434777

DIR London

Unit 1 River Road Business Park,
33 River Road, Barking,
Greater London, 1G11 0DA

Email: dirsalon@gmail.com
Phone: +44 (0) 20 8591 9310

DIR New York

575 Underhill Blvd Suite #170
Syosset, NY 11791, USA

Email: sales@dirsalonfurniture.com
Phone: +1 (718) 628 6668
+1 (800) 728 2008
Fax: +1 (855) 628 5168